

When is a site ready for sound insulation testing?

A site is ready for testing when...

- Windows are fully fitted, complete with ironmongery.
- Window trickle vents are in place or temporarily blocked up for testing.
- Room and main doors are in place and closeable.
- All wall surfaces in rooms to be tested are complete (including sockets and switches if applicable).
- Floor and ceiling surfaces are complete.
- Cornice and skirting boards are in place.
- Carpets or timber laminates have **NOT** been laid in rooms where floors are to be tested (with the exception of bonded carpet).
- Power is available on site (110V or 240V)
- Staff made aware that a quiet site environment is required during testing.
- We've been advised of any specific Health & Safety issues.

Did you know?...

RMP also offers **air tightness testing** !

Contact us for our competitive rates when arranged with your sound tests!

Other services include...

- Full acoustic design of buildings
- Noise, dust & vibration monitoring
- Environmental noise assessments
- Workplace noise assessments
- Thermographic imaging
- ... and much more!

Once the site is ready, contact RMP to arrange a booking!

We normally require a weeks' notice to ensure availability of testing personnel and equipment.

www.rmp.biz / rmp@napier.ac.uk / 0345 062 0000

RMP will work with the contractor to achieve a satisfactory result. However plot re-tests/additional testing, late cancellations (within 1 working day) or where allocated time allowances are not met due to on-site factors beyond our control, may be charged at our discretion at the rates contained within our quotation.